



VX8600

Quick Start Guide



How to
Get Music



Playing
Music



Bluetooth®
Pairing



Sending
a vCard



Taking a Picture/
Recording a Video

www.LGUSA.com

Getting to Know Your Phone

Volume Up/Down

Camera

Voice Command/
Speakerphone
Key** (unlocks
touch keys)

Camera/
Video Key

Web*

Picture & Video*

Left Soft Key

Calendar*

Send Key

Voicemail Key

Vibrate
Mode Key

OK Key

Get It Now*

Right Soft Key

Clear &
Back Key

Power/End Key

microSD™ Port

Charging Port/
Headset Adapter Port

Speaker

Touch Music Keys

* Customizable shortcut keys.

** Speakerphone feature is only available while a call is in progress.

How to Get Music

Walkin', talkin', rockin'. Transform your wireless phone into a portable music player, then expand your collection with the Verizon Wireless music catalog.


V CAST Music

1. Press **right** on the Navigation Key, select **Music & Tones (1)**, then **V CAST Music (1)** to download new music.
2. Choose from over 1,000,000 songs! Downloaded songs are stored in **My Music**.

Sync Music from PC to Phone

1. Connect your phone to your PC with an optional USB cable.*
2. Press **right** on the Navigation Key, select **Music & Tones (1)**, then **Sync Music (6)** to sync music from PC to phone. USB cable and Windows Media Player 10 are required.

**Sold separately.*




Playing Music



The VX8600 doesn't miss a beat with its built-in music player. You can store tons of music on an optional microSD card and even listen to them in stereo sound through a Bluetooth headset!

Flip Open

1. Press **right** on the Navigation Key, select **Music & Tones (1)**.
2. Select **My Music (4)**, choose a category, then press **OK** to play.
3. Use the side **Volume Keys** ◀ ▶ to adjust volume when a song is playing.
4. Press the **End Key** to exit the music player.

Flip Closed

1. Press the **Voice Command/Speakerphone Key**  twice to unlock the external keys, then tap and *hold* the ▶/|| **Key**.
2. Tap the ◀◀ or ▶▶ **Keys** to scroll through songs.
3. Tap and *hold* the ▶/|| **Key** to exit the music player



Note: To turn on Music Only Mode (RF off except Bluetooth), press **right** on the Navigation Key, select **Music & Tones (1)**, press the **Left Soft Key for Mode**, select **On** and press **OK**.


Bluetooth Pairing

Enjoy hands-free entertainment and communication in the car, office, or at home with Bluetooth accessories, like a Bluetooth stereo headset for listening to music. Get wire-free convenience up to 30 feet away.

1. Set your Bluetooth accessory into pairing mode.*
2. Press **OK** , press **down** on the Navigation Key twice to access the **SETTINGS & TOOLS** menu.
3. Select **Bluetooth Menu (7)**, then **Add New Device (1)**.
4. If Bluetooth is set to off, you will be prompted to turn power on. Select **Yes (1)** and press **OK** .
5. The phone will now search for the accessory. Once found, highlight it and press **OK** to pair.
6. Enter the passcode (typically "0000" - 4 zeroes) and press **OK** .*
7. Press **OK** to connect with the device.

**Refer to the user manual of your Bluetooth accessory to activate pairing mode and for the passcode.*


Note: Bluetooth accessories sold separately. Phone does not support all Bluetooth OBEX profiles. For vehicle/accessory compatibility, go to www.verizonwireless.com/bluetoothchart.



Sending a vCard

Sharing contact information made easy. Send a vCard (electronic name card) to easily exchange names and phone numbers to another vCard-supported mobile phone or device via Bluetooth technology.






1. Press **OK** twice, select **My Name Card (5)**.
2. Press **OK** to edit your contact information.
3. Press **Right Soft Key** for **Options**, then **Send Name Card (1)**.
4. If Bluetooth is off, select **Yes (1)** and press **OK**.
5. Select a paired device from the list and press **OK** to send.






Note: To send name cards from your contacts list, select a paired Bluetooth device and press **OK**. Then mark the name card(s) that you want to send.

Taking a Picture/Recording a Video

Shooting photos on-the-fly has never been easier with the 1.3 megapixel camera. When you need to capture all the action, get it with live video and share it all instantly with Picture/Video Messaging.

1. To activate camera mode: With the flip open, press the side **Camera/Video Key** .
2. To activate video mode: With the flip open, press and *hold*  for 2 seconds.
3. Press **left** or **right** on the Navigation Key to zoom. Press **up** (or **down**) to adjust brightness. Press the **Right Soft Key** to adjust camera/video options.
4. Press  to take a photo or record a video. Press  to stop recording.
5. Press the **Left Soft Key** to save or  to send.

Note: To take a self-portrait with the flip closed, press and *hold*  and press  again to take the picture. You can record up to 1 hour of video depending on available memory. Videos can be set as wallpapers.



Optional Accessories

Accessories for convenience and fashion are available at www.VerizonWireless.com.



Headset Adapter with
Charging Port



Bluetooth Stereo Headset



Swivel Holster



Portable Stereo Speakers



Extended Li-Polymer Battery
(1,400 mAh)



Portable Battery Charger

©2006 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated. The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.